



250 W. Adams Street Waterman, IL 60556-0218  
Phone: 815-264-3322 Toll Free: 800-833-2290  
Fax: 815-264-3324 [www.MTP78.com](http://www.MTP78.com)

## infield **CONSTRUCTION**



**Step 1:** Position recommended number of bags on skinned area. Empty and spread with drag mat.



**Step 2:** Blend into top 3" of soil with rototiller.



**Step 3:** Moisten infield and roll with mechanical or hand roller.



**Step 4:** Drag until level. Topdress.